

MONTERINGSANVISNING FÖR TAIKA

Taika-panelen monteras på väggen på samma sätt som en normal träpanel. Avståndet mellan de stående reglarna kan vara max. c/c 600 mm.

Taika-panelerna fästs i reglarna genom sponten, varvid spiken eller skruven som används för fastsättningen döljs under sponten. Lämpligt spikningsavstånd är ca 10 mm från spontens kant. För fastsättningen rekommenderas användning av rostfria skruvar eller spikar. Spik- eller skruvhuvudet ska sjunka en aning in i träet, för att det ska vara lätt att montera följande panel.

Tryck omsorgsfullt fast panelen som ska monteras i den föregående panelen, så att sponterna sitter fast i varandra. Du kan knacka på panelens kant med en hjälp av en tråkloss och hammare, för att säkerställa att sponten sluts. På detta sätt hålls avståndet mellan panelerna jämnt på 4 mm och spik- eller skruvhuvudena blir dolda.

Vid väggmontering rekommenderas att man börjar nedifrån med honsponten nedåt. Om panelindelningen inte går jämnt ut, klyv inlednings- eller avslutningspanelen till lämpligt mått. Bearbeta panelen så att den ytbehandlade sidan inte skadas.

TAIKA INSTALLATION GUIDE

The Taika panels are installed on a wall the same way as regular wood panels. The maximum distance between vertical frames is c/c 600 mm.

The Taika panels are attached to the framing through grooves, which conceal the nails or screws used to attach the panels. The suitable distance for inserting the nails or screws is approximately 10 mm from the edge of a groove. We recommend installing the panels using stainless steel screws or nails. The nail or screw head should be slightly embedded into the panel to make it easier to install the next panel.

Press the panel you are installing carefully against the previous panel so that the tongue and groove are flush against each other. You can gently tap the edge of the panel with a piece of wood and a hammer to achieve an even joint. This conceals screw or nail heads and ensures that the gap between the panels is 4 mm throughout the installation.

In a wall installation, we recommend starting from the bottom and placing the first panel with the groove end pointing towards the floor. If you cannot achieve even panelling, trim the first and last panel to suitable width. Handle the panels with care to avoid damaging the treated side.

