

Hagmans - Snickerifärg 40

Product Description

Hagmans Carpentry Paint 40 is a water-based paint, based on Hagmans' unique PAA technology. The paint provides a hard yet flexible surface. It has high covering power and is suitable for new or repainting of all types of wooden surfaces or rust-protected metal indoors. For example, doors, kitchen doors, moldings, furniture and most substrates made of primed wood, chipboard, etc. The paint has very good flow, and it remains "open" for a relatively long time to enable subsequent smoothing.

Areas of use

Can be painted on doors, kitchen cabinets, moldings, furniture and most primed wood surfaces.

Technical data:

Parameter	Value	Unit	Method
Area of application	Indoor/Outdoor		
Binder	PU alkyd/acrylate		
Colour	White + Bases		
Completely dry	24 hours (At 23°C and 50% RH)		
Density	1,3		
Dust dry	2 hours (At 23°C and 50% RH)		
Flammability	Not flammable		
Gloss	40	60°	
Washability	Class 1		
Material consumption	8-10		
Re-paintable	8 hours (At 23°C and 50% RH)		
Hiding Power	9,4 - RAL 9010		
Temperature at painting	Minimum +5°C		
Thinner/Cleaning	Water		
Tools for painting	Brush, Roller, Sprayer		
VOC category	(Cat A/d): 130 g/l		
Volume Solids	37%	%	

Parameter	Value	Unit	Method
Washability	Class 1, EN 13300		
Weight Solids	52%		

Application Instructions

Before Painting

Always start by reading the instructions on the can and remember to be careful from the beginning. Good tools and careful preliminary work are the prerequisites for a successful painting result. Stir the paint well from the bottom before you start painting. Room and surface temperature are also important for the final result. Do not paint if it is colder than +5°C. Wooden surfaces: The surface must be clean, dry and firm. Scrape off old, loose paint. Sand and wash previously painted surfaces with painter's wash and rinse with water and let dry well. Untreated wood indoors should be primed with Snickerigrund. Let dry well before lightly sanding with sandpaper to remove raised fibers. Fill in any unevenness. Sand smooth. Prime with undiluted Snickerigrund, sand with fine sandpaper and wipe clean of dust before finishing painting. Remember to protect floors and furniture properly before you start painting.

Painting

The paint is applied with a suitable high-quality paint brush, paint roller or, after thinning with 10–20% water, with a sprayer. On larger surfaces, the paint can be rolled with a short-haired roller before smoothing with a paint brush. Please test first for best results. Finish with at least 2 coats with time for drying in between.

After Painting

Dry the tools thoroughly before cleaning in water. Close the can tightly after use and store out of reach of children. Liquid paint residues should not be poured down the drain but left at the local environmental station. Paint residues must not be poured down the drain. Metal handles should be separated from the plastic can when recycling the can.

Maintenance

Use a cloth dampened with water and mild detergent to clean the surface. Never use alcohol to clean paint or varnish.

Informationen i detta dokument bygger på vår aktuella kunskap från laboratorietester och praktisk erfarenhet och kan ändras utan föregående meddelande; använd alltid senaste versionen. Produkten är endast avsedd för angivna användningsområden och, om tillämpligt, industriellt/yrkesmässigt bruk. Produkten är utformad och testad för att uppfylla gällande säkerhetskrav enligt produktansvarslagen. Användaren ansvarar för att produkten är lämplig för det specifika objektet och applikationssättet, samt att noggrant följa bruksanvisning, säkerhetsdatablad och gällande lagar. Underlåtenhet att följa detta sker på användarens egen risk.

Vi garanterar att produkten överensstämmer med våra specifikationer vid leveranstillfället. Vi ska under inga omständigheter ansvara för indirekta skador (såsom utebliven vinst, produktionsbortfall och andra följdskador) och vårt sammanlagda ansvar är begränsat till ersättning eller utbyte upp till fakturavärdet.

Vid osäkerhet om produktens lämplighet ska användaren kontakta oss innan användning. Vid reklamation ska dokumentation som styrker korrekt användning kunna uppvisas, annars kan reklamationen avslås.

För konsumentköp gäller konsumentköplagen och denna ansvarsfriskrivning begränsar inte konsumentens lagstadgade rättigheter.