




HOW TO USE LUCIE TABLE LAMP



Timer function

When the lamp is on, press and hold the button until the indicator light turns blue to activate the timer function (6 h on / 18 h off).

Warning: Light source is not replaceable.



PR HOME

Via redsvägen 32, 504 64 Borås | +46 33 - 13 33 49 | info@prhome.se | prhome.se