





Hanko Sauna SQ





Wall numbering

The wall panels are numbered on their sides, corresponding to the layout diagram below.









Numbers on each box indicate which wall panels it contains.



Wall section for heater




Information



Tip!

Information





Cardboard packaging

Use as floor protection
during assembly.

Wall panel - quality

① Both inside and outside surfaces visible - quality A

② Only external visible - quality C







See panel
label for information


Panel direction

Panel direction varies according to room orientation
Also, see enclosed layout.


Information




Mounting plate







Mounting plate - corner








Mounting plate - between walls









1 P1






Corner posts





Pre-assembled







Mounting corners - It is always recommended that the corner posts and walls are screwed together. If Space is limited, walls can be assembled and then slid into the correct location.









3







4






5




100mm



6




7









8

Door

Follow the instructions supplied with the door.





9



Ceilings

See page 7 for heater cabling instructions.







Ceilings, inside



NOTE! Make sure of correct alignment above the door.

P8



45x3.2x600mm





10










Guide bar









Option










11










12




13












* The dimensions must be equal on the diagonals



Benches




NOTE! Assemble the interior according to the safety distances in the heater's installation instructions.



Bench supports:


Use 494mm long bench support for the upper bench. Follow guide markings on side walls for correct placement. Ensure the top supports extend to the backwall





Glue and screw bench supports in place.
Make sure all screw holes are used!




16



17




Repeat steps 16-18 on left hand side





Repeat steps 19-21 on left hand side



Glue and screw bench supports in place.
Make sure all screw holes are used!



20







Secure the benches





BACKREST

22




SKIRTINGS




23



Use guide markings




24




HEATER GUARD


See heater manual for safety distance and placement of heater guard




25



28



29



See heater manual for wall placement

29

